

# フレーム番号明細

SFV650K9 100台

フレームNO(全桁)
JS1CX111200100144
JS1CX111200100145
JS1CX111200100146
JS1CX111200100147
JS1CX111200100148
JS1CX111200100149
JS1CX111200100150
JS1CX111200100151
JS1CX111200100152
JS1CX111200100153
JS1CX111200100174
JS1CX111200100175
JS1CX111200100176
JS1CX111200100177
JS1CX111200100178
JS1CX111200100179
JS1CX111200100180
JS1CX111200100181
JS1CX111200100182
JS1CX111200100183
JS1CX111200100184
JS1CX111200100185
JS1CX111200100186
JS1CX111200100187
JS1CX111200100188
JS1CX111200100189
JS1CX111200100190
JS1CX111200100191
JS1CX111200100192
JS1CX111200100193
JS1CX111200100194
JS1CX111200100195
JS1CX111200100196
JS1CX111200100197
JS1CX111200100198
JS1CX111200100199
JS1CX111200100200
JS1CX111200100201
JS1CX111200100202
JS1CX111200100203
JS1CX111200100204
JS1CX111200100205
JS1CX111200100206
JS1CX111200100207
JS1CX111200100208
JS1CX111200100209
JS1CX111200100211
JS1CX111200100212
JS1CX111200100213
JS1CX111200100214
JS1CX111200100215
JS1CX111200100216
JS1CX111200100217
JS1CX111200100218
JS1CX111200100219
JS1CX111200100220
JS1CX111200100221
JS1CX111200100222
JS1CX111200100223
JS1CX111200100224

SFV650K9

フレームNO(全桁)
JS1CX111200100225
JS1CX111200100227
JS1CX111200100229
JS1CX111200100230
JS1CX111200100231
JS1CX111200100235
JS1CX111200100236
JS1CX111200100237
JS1CX111200100238
JS1CX111200100239
JS1CX111200100240
JS1CX111200100241
JS1CX111200100242
JS1CX111200100243
JS1CX111200100244
JS1CX111200100245
JS1CX111200100246
JS1CX111200100247
JS1CX111200100248
JS1CX111200100249
JS1CX111200100250
JS1CX111200100251
JS1CX111200100252
JS1CX111200100253
JS1CX111200100254
JS1CX111200100255
JS1CX111200100256
JS1CX111200100257
JS1CX111200100258
JS1CX111200100259
JS1CX111200100260
JS1CX111200100261
JS1CX111200100262
JS1CX111200100263
JS1CX111200100266
JS1CX111200100267
JS1CX111200100268
JS1CX111200100272
JS1CX111200100273
JS1CX111200100274

SFV650AK9 29台

フレームNO(全桁)
JS1CX112200100001
JS1CX112200100002
JS1CX112200100003
JS1CX112200100004
JS1CX112200100005
JS1CX112200100006
JS1CX112200100007
JS1CX112200100008
JS1CX112200100009
JS1CX112200100010
JS1CX112200100012
JS1CX112200100013
JS1CX112200100014
JS1CX112200100015
JS1CX112200100016
JS1CX112200100017
JS1CX112200100018
JS1CX112200100019
JS1CX112200100020
JS1CX112200100021
JS1CX112200100022
JS1CX112200100023
JS1CX112200100024
JS1CX112200100025
JS1CX112200100026
JS1CX112200100027
JS1CX112200100028
JS1CX112200100029
JS1CX112200100030

SFV650L0 50台

フレームNO(全桁)
JS1CX111100107451
JS1CX111100107453
JS1CX111100107554
JS1CX111100107556
JS1CX111100107603
JS1CX111100107604
JS1CX111100107605
JS1CX111100107606
JS1CX111100107607
JS1CX111100107608
JS1CX111100107664
JS1CX111100107665
JS1CX111100107666
JS1CX111100107667
JS1CX111100107668
JS1CX111100107669
JS1CX111100107670
JS1CX111100107671
JS1CX111100107672
JS1CX111100107673
JS1CX111100107674
JS1CX111100107675
JS1CX111100107676
JS1CX111100107677
JS1CX111100107678
JS1CX111100107679
JS1CX111100107680
JS1CX111100107681
JS1CX111100107682
JS1CX111100107683
JS1CX111100107684
JS1CX111100107685
JS1CX111100107686
JS1CX111100107687
JS1CX111100107688
JS1CX111100107689
JS1CX111100107690
JS1CX111100107691
JS1CX111100107692
JS1CX111100107693
JS1CX111100107917
JS1CX111100107921
JS1CX111100107942
JS1CX111100107943
JS1CX111100107944
JS1CX111100107945
JS1CX111100107947
JS1CX111100107948
JS1CX111100107949
JS1CX111100107950

## SFV650AL0 50台

フレームNO(全桁)
JS1CX112100102037
JS1CX112100102039
JS1CX112100102053
JS1CX112100102058
JS1CX112100102059
JS1CX112100102060
JS1CX112100102083
JS1CX112100102086
JS1CX112100102110
JS1CX112100102114
JS1CX112100102139
JS1CX112100102140
JS1CX112100102141
JS1CX112100102142
JS1CX112100102143
JS1CX112100102144
JS1CX112100102145
JS1CX112100102146
JS1CX112100102147
JS1CX112100102148
JS1CX112100102149
JS1CX112100102150
JS1CX112100102151
JS1CX112100102152
JS1CX112100102153
JS1CX112100102154
JS1CX112100102155
JS1CX112100102156
JS1CX112100102157
JS1CX112100102158
JS1CX112100102216
JS1CX112100102217
JS1CX112100102241
JS1CX112100102242
JS1CX112100102253
JS1CX112100102254
JS1CX112100102255
JS1CX112100102256
JS1CX112100102271
JS1CX112100102272
JS1CX112100103055
JS1CX112100103056
JS1CX112100103085
JS1CX112100103087
JS1CX112100103088
JS1CX112100103090
JS1CX112100103120
JS1CX112100103134
JS1CX112100103135
JS1CX112100103171

## SFV650L1 40台

フレームNO(全桁)
JS1CX111100108655
JS1CX111100108660
JS1CX111100108695
JS1CX111100108698
JS1CX111100108699
JS1CX111100108700
JS1CX111100108705
JS1CX111100108706
JS1CX111100108709
JS1CX111100108710
JS1CX111100108723
JS1CX111100108724
JS1CX111100108726
JS1CX111100108727
JS1CX111100108728
JS1CX111100108760
JS1CX111100108761
JS1CX111100108762
JS1CX111100108765
JS1CX111100108766
JS1CX111100109403
JS1CX111100109404
JS1CX111100109405
JS1CX111100109406
JS1CX111100109407
JS1CX111100109408
JS1CX111100109409
JS1CX111100109410
JS1CX111100109411
JS1CX111100109412
JS1CX111100109802
JS1CX111100109805
JS1CX111100109806
JS1CX111100109810
JS1CX111100109813
JS1CX111100109831
JS1CX111100109833
JS1CX111100109834
JS1CX111100109835
JS1CX111100109836

## SFV650AL1 100台

フレームNO(全桁)
JS1CX112100103962
JS1CX112100103963
JS1CX112100103964
JS1CX112100103965
JS1CX112100103966
JS1CX112100103967
JS1CX112100103968
JS1CX112100103969
JS1CX112100103970
JS1CX112100103971
JS1CX112100103972
JS1CX112100103973
JS1CX112100103974
JS1CX112100103975
JS1CX112100103976
JS1CX112100103977
JS1CX112100103978
JS1CX112100103979
JS1CX112100103980
JS1CX112100103981
JS1CX112100103982
JS1CX112100103983
JS1CX112100103984
JS1CX112100103985
JS1CX112100103986
JS1CX112100103987
JS1CX112100103988
JS1CX112100103989
JS1CX112100103990
JS1CX112100103991
JS1CX112100103992
JS1CX112100103993
JS1CX112100103994
JS1CX112100103995
JS1CX112100103996
JS1CX112100103997
JS1CX112100103998
JS1CX112100103999
JS1CX112100104000
JS1CX112100104001
JS1CX112100104255
JS1CX112100104256
JS1CX112100104257
JS1CX112100104258
JS1CX112100104259
JS1CX112100104260
JS1CX112100104261
JS1CX112100104262
JS1CX112100104263
JS1CX112100104264
JS1CX112100104365
JS1CX112100104366
JS1CX112100104367
JS1CX112100104368
JS1CX112100104369
JS1CX112100104370
JS1CX112100104371
JS1CX112100104372
JS1CX112100104373
JS1CX112100104374

## SFV650AL1

フレームNO(全桁)
JS1CX112100104815
JS1CX112100104816
JS1CX112100104817
JS1CX112100104818
JS1CX112100104819
JS1CX112100104820
JS1CX112100104821
JS1CX112100104822
JS1CX112100104823
JS1CX112100104824
JS1CX112100105578
JS1CX112100105579
JS1CX112100105580
JS1CX112100105581
JS1CX112100105582
JS1CX112100105583
JS1CX112100105584
JS1CX112100105585
JS1CX112100105586
JS1CX112100105587
JS1CX112100105588
JS1CX112100105589
JS1CX112100105590
JS1CX112100105591
JS1CX112100105592
JS1CX112100105593
JS1CX112100105594
JS1CX112100105595
JS1CX112100105596
JS1CX112100105597
JS1CX112100105599
JS1CX112100105600
JS1CX112100105601
JS1CX112100105602
JS1CX112100105603
JS1CX112100105604
JS1CX112100105605
JS1CX112100105607
JS1CX112100105608
JS1CX112100105609